



Windows Driver for the Uno and Go Link

Ensure you have unzipped the file. Open the unzipped file, Click on the “iFi USB Device Driver” to start the install.

Install the USB Driver for your Uno or Go-Link.



If you get this screen, click [More info](#).



Click on [Run Anyway](#). This will let the program install on your PC/Laptop

iFi iFi USB Audio Device Driver

— □ ×

Welcome to iFi USB Audio Device Driver Setup



Setup will guide you through the installation of iFi USB Audio Device Driver.

It is recommended that you close all other applications before starting Setup. This will make it possible to update relevant system files without having to reboot your computer.

Click Install to start the installation.

Install

Cancel

[Install](#).

iFi iFi USB Audio Device Driver

— □ ×

Completing iFi USB Audio Device Driver Setup



iFi USB Audio Device Driver has been installed on your computer.

Click Finish to close Setup.

< Back

Finish

Cancel

[Finish](#).

You may be asked to plug in your device in to complete the install.