


How to upgrade your unit to version 7.0C on Windows.

You can find a video that walks you through the instructions below here:
<https://youtu.be/xfv32H0QoIM>.


Step 1: Locate the drivers folder.

1. Make sure you have the iFi Windows drivers downloaded on your Windows machine.
2. Locate the folder: C://Program Files/iFi/USB_HD_Audio_Driver and double click on the iFiHDUSBAudio_dfuapp.exe file.




Step 2: Load the firmware file.

Load the firmware file by pressing the “Browse...” button and locating the ‘iFi_XMOS_7.0C_XU216.bin’ file (it should be located in the same folder as this guide).



Step 3: Upgrading the firmware.

Upgrade the firmware by clicking "Start".



When it is done, it will say "Firmware upgrade finished successfully."

After the upgrade, please unplug the iFi device from your computer and completely power it OFF before first use.

Note: On some computers, one needs to perform the upgrade process twice for the upgrade to be successful. After the first go, the firmware version may still report it has the original version, in which case, press "Start" again to perform another upgrade (sometimes it just takes two attempts).

If you have any further questions, please open ticket in our [support system](#).